

# Contactor Replacement Parts



## REPLACEMENT CONTACT KITS

MODEL NUMBER	DESCRIPTION	CONTACTOR	LIST PRICE
🖱 RSC-T100	EACH KIT INCLUDES: 3 STATIONARY AND 3 MOVABLE CONTACTS  (REPLACES ALL THREE PHASES OF ONE CONTACTOR)	RSC-100	CF
🖱 RSC-T125		RSC-125	CF
🖱 RSC-T150		RSC-150	CF
🖱 RSC-T180		RSC-180	CF
🖱 RSC-T220		RSC-220	CF
🖱 RSC-T300		RSC-300	CF
🖱 RSC-T400		RSC-400	CF
🖱 RSC-T600		RSC-600	CF
🖱 RSC-T800		RSC-800	CF


## REPLACEMENT PHASE BARRIER KITS

MODEL NUMBER	DESCRIPTION	FRAME	LIST PRICE
🖱 RSC-B125	EACH KIT INCLUDES: 2 PHASE BARRIERS FOR LINE OR LOAD SIDE OF ONE CONTACTOR	RSC-100~125	CF
🖱 RSC-B150		RSC-150	CF
🖱 RSC-B220		RSC-180~220	CF
🖱 RSC-B400		RSC-300~400	CF
🖱 RSC-B800		RSC-600~800	CF



## CONTACTOR COILS

MODEL NUMBER	COIL VOLTAGE	CONTACTOR RANGE	LIST PRICE
🖱 RSC-C40-*	AC	RSC-9~40	CF
🖱 RSC-C22-DC-*	DC	RSC-9~22	CF
🖱 RSC-C40-DC	DC	RSC-32~40	CF
🖱 RSC-C85-*	AC	RSC-50~85	CF
🖱 RSC-C85-DC*	DC	RSC-50~85	CF
🖱 RSC-C150-*	UNIVERSAL	RSC-100~125~150	CF
🖱 RSC-C220-*	UNIVERSAL	RSC-180~220	CF
🖱 RSC-C400-*	UNIVERSAL	RSC-300~400	CF
🖱 RSC-C800-*	AC	RSC-600~800	CF



\* Refer to coil voltage page 1-7 for complete part number.

\* AC and DC coils are not interchangeable.

🖱 Web stocked