

# Prepackaged Starters with Integral Bypass Non-Combination 480V

## MX2PB SERIES

NEMA 4/12



### NON-COMBINATION

MODEL NUMBER	STD DUTY <sup>1</sup> HP	HEAVY DUTY <sup>2</sup> HP	VOLT	DIMENSIONS (IN)			WGT (LBS)	LIST PRICE
				H	W	D		
MX2PB-030-4-4-NC- <sup>**2</sup>	30	30	480	24	16	15	110	CF
MX2PB-050-4-4-NC- <sup>**2</sup>	50	40	480	24	16	15	110	CF
MX2PB-075-4-4-NC- <sup>**2</sup>	75	75	480	36	16	15	150	CF
MX2PB-100-4-4-NC- <sup>**2</sup>	100	—	480	36	20	15	150	CF
MX2PB-150-4-4-NC- <sup>**2</sup>	150	150	480	48	20	15	180	CF
MX2PB-200-4-4-NC- <sup>**2</sup>	200	—	480	48	20	15	180	CF
MX2PB-300-4-4-NC- <sup>**2</sup>	300	200	480	48	20	15	180	CF
MX2PB-400-4-4-NC- <sup>**2</sup>	400	300	480	78	30	20	350	CF

<sup>\*\*</sup> Insert option code as shown below.

See page 5-29 for a list of available options.

ST = No options

OP = Options included

<sup>1</sup> Standard duty = 350% current for 30 seconds, 1.15 S.F.

<sup>2</sup> Heavy duty = 500% current for 30 seconds, 1.25 S.F.

#### LEAD TIME:

In stock for same day shipment ... or modified for next day shipment.

Web stocked

# Prepackaged Starters Non-Bypassed / Continuous Duty and Integral Bypass

## MX2PB / MX2PC SERIES

PREPACKAGED STARTERS WITH NEW MX<sup>2</sup> TECHNOLOGY  
MODIFIED FOR NEXT DAY SHIPMENT



*Configure the  
MX2PB / MX2PC to  
fit your application ...*

To choose a stock starter, simply select a unit from the following price pages.  
To modify a starter, select a unit from the following price pages, then add an alpha board and/or other options as needed from the *Options* section ... Benshaw will modify the stock unit for next day shipment.

- 1. Select a starter type:**
  - MX2PC modular non-bypass or
  - MX2PB modular bypassed
- 2. Select a horsepower rating**
- 3. Select a voltage**
- 4. Select an enclosure**
- 5. Select a circuit breaker (or none)**
- 6. Select your options**

- See page 5-22 for part number assembler
- See pages 5-26 and 5-28 for stock units
- Price pages start on page 5-23
- See options on page 5-29

*MX2PB / MX2PC  
configurable solid state  
starters are stocked as:*

- ◆ Non-combination
- ◆ Combination circuit breaker
- ◆ Rotary disconnect operator
- ◆ Non-bypass
- ◆ Bypass contactor
- ◆ NEMA 4 or 12 enclosure
- ◆ Modular operator station
- ◆ 480 volt
- ◆ Standard 120V control power transformer
- ◆ Service entrance rated with circuit breaker

*Configurable to:*

- ◆ Options shown on page 5-29



(STOCK  
UNIT  
SHOWN)

+



=

